

**SHEET NOTES:**

- SEE <sup>1</sup> AREA SWITCHING SCHEMATICS FOR LIGHTING CONTROL.  
E3.00 E4.40  
E4.10  
E4.11  
E4.12  
E4.20
- VERIFY SITE LIGHTING BRANCH CIRCUIT LOADING PRIOR TO DISCONNECTION. NOTIFY ENGINEER FOR REDESIGN OF ANY OVERLOADED CIRCUITS AND/OR AREAS WHERE DESIRED LIGHTING CONTROL CANNOT BE ACHIEVED. REMOVE BRANCH CIRCUITING BEGINNING AT ROOM ELECTRICAL 130 TO THE FIRST JUNCTION BOX THAT IS OUTSIDE OF THE DEMOLISHED AREA AND SUITABLE TO USE FOR CIRCUIT RECONNECTION. INSTALL NEW CIRCUITING, SIZED BASED UPON DOCUMENTED CIRCUIT LOAD, FROM RECONFIGURED ROOM ELECTRICAL 130 TO JUNCTION BOX. DOCUMENT ALL CIRCUITING FOR AS-BUILT DRAWING SET.
- FIXTURES SHOWN WITHOUT A KEYED NOTE ARE EXISTING.

**KEYED NOTES:**

- EXISTING BUILDING AT SOUTHWEST PROPERTY CORNER OF PROJECT NOT PART OF CONTRACT.
- RELOCATED POLE. SEE SHEET E2.00
- COORDINATE EXACT LOCATION OF BOLLARD WITH INSTALLATION OF SIGN PRIOR TO ROUGH-IN. SEE ARCHITECTURAL PLAN A003. CIRCUIT THRU CONTACTOR PANEL WITH OTHER EXTERIOR FIXTURES.
- INSTALL KIM SMZ/BL-P TENON IN 18"x36" CONCRETE BASE 24" BEHIND CURB.
- INSTALL WALL PACKS, REMOVED DURING DEMOLITION PHASE. SPACED EVENLY ALONG WALL AT SAME HEIGHT AS SIMILAR WALL PACKS THAT REMAINED AFTER DEMOLITION.
- STANCHION-MOUNTED RECEPTACLE. COORDINATE EXACT LOCATION WITH ARCHITECT/OWNER PRIOR TO ROUGH-IN.
- SEE PATTISON SIGN PRODUCTION DRAWINGS FOR SIGNAGE POWER CONNECTION DETAILS PRIOR TO ROUGH-IN.

